




| | | | |
|--|--------------------------|---------------|---------------------|
| Type : M200W - ZWART | From mach. nr. : 4R31423 | Page : 1 -2 | Drawer : EW |
| Artikelnummer : 10557 | Date : 12-2008 | Rev. : 0.0 | Date : 12-11-2008 |
| Rated voltage : 1N~ 220-240V 50-60Hz 3350W | Spare Parts Info | Animo® | www.animo.eu |



page 1-2 page 2-2

* Recommended Spare Part

Type : M200W - ZWART
 Artikelnummer : 10557

From mach. nr. : 4R31423
 Date : 12-2008

Page : 2 -2
 Rev. : 0.0


Drawer : EW
 Date : 12-11-2008

Rated voltage : 1N~ 220-240V 50-60Hz 3350W

Spare Parts Info



www.animo.eu



01234 = SPARE PART - ZIE/SEE/SIEHE/VOIR : SPARE PARTS INFO

- bl blauw. blue. blau. bleu.
- br bruin. brown. braun. brun.
- gl geel. yellow. gelb. jaune.
- gr groen. green. grün. vert.
- ps paars. purple. violett. violet
- gs grijs. gray. grau. gris.
- rd rood. red. rot. rouge.
- rs roze. pink. rosa. rose.
- wt wit. white. weiß. blanc.
- zw zwart. black. Schwarz. noir

Type : M200W - ZWART

Artikel : 10557

From mach.nr. : 4R31423

Date : 01-12-08

Page : 1-2

Rev. : 0

Drawer : W.B

Date : 01-12-08

Checked :


Drawing nr. : S10557

Rated voltage: 1N~ 220-240V 50-60Hz 3350W

CIRCUIT DIAGRAM

Animo[®]
Premium coffee makers and beverage equipment

S10557BL1



[01234] = SPARE PART - ZIE/SEE/SIEHE/VOIR : SPARE PARTS INFO

- bl blauw. blue. blau. bleu.
- br bruin. brown. braun. brun.
- gl geel. yellow. gelb. jaune.
- gr groen. green. grün. vert.
- ps paars. purple. violett. violet
- gs grijs. gray. grau. gris.
- rd rood. red. rot. rouge.
- rs roze. pink. rosa. rose.
- wt wit. white. weiß. blanc.
- zw zwart. black. Schwarz. noir

Type : M200W - ZWART

Artikel : 10557

From mach.nr. : 4R31423

Date : 01-12-08

Page : 2-2

Rev. : 0

Drawer : W.B

Date : 01-12-08

Checked :

Drawing nr. : S10557

Rated voltage: 1N~ 220-240V 50-60Hz 3350W

CIRCUIT DIAGRAM

Animo[®]
Premium coffee makers and beverage equipment